





Installation Manual





A x1




ST6.3x38

B x5




Ø10


C x5



D x2




x2




(x8)

ST5x30

E



F x2




x1

x1



M4x6 (x2)

G



x1

ST4.2x35 (x2)



Ø8 (x2)



H




I x1






J x1



Ø8




Ø10





45'







1





2





3




4



5



6



7

