Installation manual










2
1
(X2)
2
(X5)


3
1
(X4)
2

4



5



6


Door stopper can be installed at the end of track.
1
2
3
Door stopper can be also installed between two wall mounts.

7


Door stopper can be installed at the end of track.
1
2
3
Door stopper can be also installed between two wall mounts.